

Instructions for 5255A Conversion Kit for Rowe BC 3500 to a Mars Validator

READ INSTRUCTIONS COMPLETELY BEFORE BEGINNING INSTALLATION
TURN OFF POWER AND UNPLUG THE BILL CHANGER
BEFORE BEGINNING INSTALLATION

REQUIRES MARS AE2611U7E Validator with 700 Stacker (Optional 300, 500 Stacker)

Step 1 Remove Current Bill Transport and Stacker

- A. Unplug the 15 pin bill transport plug .
- B. Pull out the current bill transport completely by sliding out along its track and unlatching the catch. (See Figure 1).
- C. Unplug the stacker harness . Remove the stacker housing/bracket by removing the 2 screws at the top of the bracket, then remove the 2 screws at the inside floor of the stacker bracket.

Figure 1 Bill transport removed / view of track for bill transport



